

*** Sometimes takes a few moments to switch over from one setting to the next***

How to turn the system on and off:

1. Click the “On/Off” button on the analog controller.



How to Switch to video conference input:

1. Click the “V. Conf.” button on the analog controller.



How to Switch to click share input:

1. Click the “C. Share” button on the analog controller.



How to Switch to Apple TV input:

1. Click the “Apple TV” button on the analog controller.



How to Switch to Sonos input:

1. Click the “Sonos” button on the analog controller.



How to adjust the volume for all inputs:

1. Click the up and down buttons on the bottom of the analog controller.

